



Technical data

		Substance
Backing		elastic PE film
Adhesive		Acrylate contact adhesive
Release film		siliconized paper
Attribute	Regulation	Value
Colour		white / blue
Exposure time		6 months
Application temperature		above -10 °C ; 14 °F
Temperature resistance		permanent -40 °C to 90 °C ; -40 °F to 194 °F
Storage		cool and dry

Area of application

COMPEGO is used to bond overlaps between vapour check and airtightness membrane securely, air tightly and permanently as well as for indoor and exterior joints between such membranes. Also suitable for bonding butt joints between woodbased panels.

Advantages

- ✓ 6 months of outdoor exposure
- ✓ With elastic backing film, can be torn off by hand
- ✓ For airtight bonds according to DIN 4108-7, SIA 180 and OENORM B 8110-2
- ✓ Waterproof adhesive
- ✓ Excellent values in the hazardous substance test, has been tested according to the ISO 16000 evaluation scheme

Substrates

Before adhesion is carried out, subsurfaces should be brushed off, wiped clean with a cloth or cleaned using compressed air. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all vapour retarder and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other underlay/sarking and wall lining membranes (e.g. those made of PP and PET).

Bonding and joints are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood fibre underlay panels).

Wood fibre sub-roof panels and smooth mineral subsurfaces require pre-treatment with TESCON PRIMER before bonding. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

General conditions

The bonds should not be subjected to tensile strain.

Once membranes have been stuck, the weight of the insulation material must be supported by laths.

Adhesion should be supported by additional laths, if necessary.

Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof bonding can only be achieved on vapour retarders or underlay/sarking/facade membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

Ametlik esindaja Eestis:
Tervemaja OÜ
Tähe 135A, 50107 Tartu
tel +372 7405 509
e-post: tervemaja@tervemaja.ee
www.tervemaja.ee

MOLL
bauökologische Produkte GmbH
Rheintalstraße 35 - 43
D-68723 Schwetzingen
Fon: +49 (0) 62 02 - 27 82.0
eMail: info@proclima.de

MOLL